

## Spectra 7 Stainless Steel Pendant



SMR 2-004152

### Installing the Pendant Back Box (Stainless Steel/Environmental/Pendant)

1. Apply thread compound (provided) to the 1.5" threads on the backbox.
2. Screw the backbox onto the mount.


### Installing the Dome Drive

1. Line up the edges of the dome drive with the inside of the backbox.
2. Push the dome drive into the clips until both sides click into place. The clips temporarily hold the dome drive in place.
3. Place one hand on or under the dome until the fasteners are secure.
4. Screw in the three captive fasteners until they are secure.



## Installing the Lower Dome


Attach the backbox leash to the lower dome using the nearest retainer screw.



### Attaching the Leash to the Stainless Steel Lower Dome

1	Leash
2	Retainer Screw

1. Lightly apply O-ring lubricant (supplied with the lower dome) to the O-ring, and then install the O-ring in the groove on the trim ring of the lower dome.
2. Remove the two lower dome mounting screws, and apply a drop of Loctite® 222MS (supplied with lower dome) to each screw.
3. Push the lower dome into the backbox, line up align the mounting screw holes, and install the two mounting screws.



4. Apply power to the dome. The dome system will complete a configuration sequence.